

LF PWR PLAY STEP

LPP-ST

Parts Manual

2/17/2025 8:05:09 AM





Table of Contents

Components.....	3
---------------------------------	-------------------

Components



Ref #	Part Number	Qty	Description
1	3236201	4	M10 X 1.5 X 20 SHCS, LOW HEAD
2	3260903	4	SCREW, M5X.8X10 PHL FLT ST BZ
3	3226003	6	6-20 X 8 PHL PAN PLT ST BZ
4	3237407	4	PLUG, 1 IN HOLE
5	7333902	1	CAP, LARGE FLOV-END; CHGR
6	7385201	4	SPACER, .406 X .750 X .250 SS
8	1022454-0001	1	ENDCAP: FLOV : INJ MOLDED
9	9123002	1	COVER, BRKT -CHR
10	9123202	2	COVER, HOOK -CHR
11	9123302	2	COVER, HOOK W/BOSS -CHR
12	9508528	1	WLDMT, STEP-UP -CHR
13	9575201	1	PLATFORM, FXT, MDF
14	9488901	1	LABEL, INSIGNIA, FCC

